



1. Line up the side flap so that the front corner of the flap (A) is just behind the first of three receivers on the base plate (B).



2. When in position as described above, push the side flap on to the base plate.



3. Slide the side flap forward to lock in to position.