



The RM3 Superior is designed to be built-in or freestanding. The low threshold and wide side-entry door allows easy access for people with various degrees of mobility. The roomy contoured seat allows the user to sit comfortably and safely in a slightly reclined position. The unique door is designed to clear the commode in small bathrooms where space is a premium.

The sleek exterior design of the RM3 Superior will give your bathroom an upscale look. Featuring a full range of standard and optional features, the RM3 Superior bathtub is designed to enhance your bathing experience.

The Rane Bathing & Accessibility product line provides a unique combination of style, ease of use, comfort, and low cost of ownership.

- 100% made in the USA. Manufactured in Sparta, TN from the highest quality components and materials.
- A “Best in Class” Warranty resulting in low cost of ownership:
 - 5 years for external finishes and composite shell
 - 3 years on all moving and stationary parts
 - Lifetime warranty on the door seal
- Full set of Standard Features including A Roman Deck Mount Valve Package made of solid brass with a polished chrome finish and a handheld shower wand.
- Full set of Optional Features including CleanRane™ Air Spa System, Supreme Combination Package, Brushed Nickel or Oil Rubbed Bronze Roman Deck Mount Package, Side Panels, 12' Filler Panel, 3/4" Supply Lines, Head Pillow, Gel Pillow, Gel Seat Cushion, Secondary Safety Latch, Lap and Shoulder Harness, and Chrome Shower Bar.
- Nationwide Distribution and Customer Service.



All Rane residential walk-in bathtubs feature a Roman Deck Mount Valve Package made of solid brass with a polished chrome finish.



The air jets on the CleanRane™ Air Spa System feature spring loaded check valves for back flow prevention, which eliminates the extra step to disinfect the air lines.



Exclusive Key Lock Design
Utilizing a proven design principle in architecture the key lock design system will guarantee the swing out door on a rane tub will not leak.

Standard Features

- Roman Deck Mount Valve Package made of solid brass with a polished chrome finish that provides an elegant look to your bathroom.
- Handheld Shower Wand for hair and upper body washing.

Optional Features

- CleanRane™ Air Spa System with variable speeds that enhance the therapeutic and relaxing effects of bathing for the user.
- Supreme Combination Package featuring CleanRane™ Air Spa System, Heated Whirlpool System, Aromatherapy, and Chromatherapy.
- Brushed Nickel or Oil Rubbed Bronze Roman Deck Mount Package.
- Side Panels for both the left or right side of the tub, which is needed for freestanding or corner installations.
- 12" Filler Panel for use when replacing an existing standard size bathtub (60"), and can be cut to required size.
- 3/4" Supply Lines constructed of stainless steel.
- Head Pillow with suction cups for comfort and head support.
- Gel Seat Cushion made with an ultra-soft viscoelastic polymer gel and custom designed to fit perfectly in our residential tubs.
- Lap and Shoulder Harness for user safety.
- Secondary Door Lock to prevent accidental door opening when in use.
- Chrome Shower Bar to install shower wand on wall, which will allow stand-up showering if desired.

TECHNICAL SPECIFICATIONS

Length:	50"
Width:	30"
Height:	40" (lowest setting)
Door Width:	34.75"
Adjustable Leveling Legs:	2" maximum
Seat Width (interior):	20"
Seat Height:	20.5"
Threshold Height:	4.5" (lowest setting)
Weight Capacity (occupant):	350 lbs / 159 kg
Water Capacity (maximum):	77 gallons
Fill Time (75 gallons):	4:15 at 60 PSI
Drain Time (75 gallons):	1 minute, 42 seconds
Water Supply Inlet:	3/4" diameter
Drain Size:	1.5"
Electrical Supply:	115V AC; 60Hz; 15 amp
Door Swing:	Outward
Door Configuration:	Right or Left Hinge



The low threshold and wide side-entry door allow easy access for people with various degrees of mobility. The unique door is designed to clear the commode in small bathrooms where space is a premium.

CleanRane™ Air Spa System

The CleanRane™ Air Spa System enhances the therapeutic and relaxing effects of bathing and provides a pleasant experience for the resident. Hydromassage provides millions of preheated air bubbles in the water which increases stimulation of peripheral blood circulation, reduces pain and inflammation in the joints, gently massages away dirt, and induces deeper relaxation. The hygienic and low maintenance CleanRane™ Air Spa System features 12 air jets with spring loaded check valves for back flow prevention, which prevents water from entering the air lines. Unlike most other whirlpool and air spa systems, the CleanRane™ Air Spa System does not allow water to enter the air lines, which can become a breeding ground for bacteria and mold. The highly efficient CleanRane™ Air Spa System simplifies disinfection and reduces the possibility of cross-contamination. The motor is quiet, efficient, and has a ceramic heating element that blows warm air to help maintain the water temperature and warm the surface of the tub.

Warranty: 5 years for external finishes and composite shell, 3 years for all moving and stationary parts, and lifetime on the door seal.

Certifications / Standards: A112.19.7-2012 / CSA B45.10-12 / UL 1795 / CSA C22.2 no. 218.2 / IAPMO Z124-2011 / CSA B45.5-



155 Norcom Way
Sparta, TN 38583
Ph: 888.880.7373
Fax: 931.836.6374

